



pushwick[®]
TECHNOLOGY
LED Candle

With Gratitude for your purchase of
Matchless Candle Co.

Our candles are made by hand with high quality
design & carefully blended fragrances.

No Match, No Mess, No Worry.



Matchless Candle Co. Limited Warranty.

This product is guaranteed to be free from defects in material and workmanship for 180 days following date of purchase. Damage caused by neglect, misuse, exposure to excessive heat/cold/moisture or improper battery installation is NOT covered by this warranty. Proof of purchase (sales receipt) is required. We're always ready to listen! We're really easy to reach by email. Shoot us a message for the fastest response at customerservice@matchlesscandleco.com. Questions or feedback? Please contact customer service at 1.844.628.2453.

Patents: www.MatchlessCandleCo.com/Patents

BATTERY INSTALLATION

- To release battery cover on bottom, push down and slide cover to the left.
- Install (4) AA Alkaline batteries. Be sure batteries are inserted in the proper direction (Fig. 1) and replace battery cover.

Note: Alkaline batteries are recommended for maximum battery life.




Fig. 1

CANDLE OPERATION

- For manual ON/OFF operation: push down on candle wick.
- To set timer: turn candle ON, push and hold the wick for 5 seconds. The lights will flash telling you the timer is set. Candle will automatically turn on the same time each day for 5 hours then turn off for 19 hours.

REMOTE READY

- Remote control sold separately (not included with all candles).



CANDLE MAINTENANCE

- Clean with a soft, dry cloth.
- If needed, use a damp cloth and mild household soap.

BATTERY SAFETY AND DISPOSAL

- Recycle or dispose of used batteries responsibly, and according to federal, state, and local laws.
- Do not mix old and new batteries. Replace all batteries at the same time.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel cadmium) batteries, or rechargeable nickel metal hydride batteries.
- Insert batteries using correct polarity (+ and -). Do not short-circuit the supply terminal.
- Failure to insert batteries correctly may shorten the life of the batteries or cause batteries to leak, which may damage the candle.
- Remove batteries from product when not in use and before extended storage.
- Always use and replace batteries under adult supervision.

CAUTION

- Candle is made of REAL WAX. Keep away from any heat source that could cause the wax to soften, melt or catch fire.
- This product is not waterproof. Place this product away from damp surroundings and do not submerge in water.
- For indoor use only.
- To avoid wax deposits or color transfer on any surface, place candle on a protective base.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FC This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation.